
WiRE installation.

- Load Wire disk into the PC and open the wire folder.
- Double click on the Setup folder then double click on setup the setup wizard will start.
- Click on Next, then accept the licence agreement and click on Next.
- At setup type, select Install wire and click on Next.
- At Choose Destination Location, click on Next.
- At Ready to Install the Program, click on Install.
- At Welcome to the InstallShield Wizard for MATLAB Component Runtime, click on Next.
- At Customer Information, click on Next
- At Destination Folder, click on Next.
- At Ready to Install the Program, click on Install.
- At Welcome to the InstallShield Wizard for MATLAB Component Runtime, click on Next.
- At Customer Information, click on Next.
- At Destination Folder, click on Next.
- At Ready to Install the Program, click on Install.
- At InstallShield Wizard Complete, click on Finish.

Next you will need to load the registry files;

- Load the registry files to the pc desktop (each registry contains two files - .usr + .sys)
- change the file format from _usr and _sys to both _reg (see attached files "change from" and "change to")
- if you have windows 7 64bit > separately drag and drop the files into the file created when you installed the software. Click yes and then ok when asked. (see attached file Regedit32)
- For windows 7 32bit > you will just need to double click on the files separately, click yes and then ok when asked.
- now click Start>all programs>Renishaw Wire**>Wire**.
- you may need to input the passwords, these can be found on the back of the installation CD.