Replacing Circuit Board in the Controller

1) Turn off the system




2) Remove lower panel cover on the right side of the XRD




3) Located the "controller"



4) Locate the B231 card, it will be stamped "B231"



- 5) Confirm the labeling is correct and remove the 5 cables that are plugged into the existing "B231" card.
- 6) Then remove the card
- 7) Compare the dip switches and make sure the new board switches are set the same as the existing board



- 8) Install board, attach cables
- 9) Turn on the system
- 10) Rehome the drives